

# FABULOUS

## SUZUKI 10HOLES FABULOUS F-20E/F-20J

**⚠ 注意** 安全に末永くご使用いただくため以下の指示を必ずお守りください。

### 演奏の前に

手を洗い、口をきれいにすぎましょう。また1音ずつゆっくり鳴らしてみ、音程がおかしくないか確認しましょう。通常より音程が大きく下がっている音があれば、リードが折れている可能性があります。その場合、使用しないでください。

### 異物を入れないで

吹口やすき間に異物を入れないでください。故障・破損の原因になります。

### カバーを強く押さないで

カバーを強く押ししたり、かんだりしないでください。変形・破損の原因になります。また、変形してできたすき間に唇や舌などが入ると思わぬケガをする恐れがあります。

### ハーモニカを投げたり落としたりしないでください

ハーモニカが破損するだけでなくケガの恐れがあり危険です。

### 熱くなる場所はさけて

車の中やストーブのすぐ近く、日ざしの強いところにおかないでください。変形・破損の原因になります。

### 通常のお手入れについて

演奏後は穴を下に向けて軽く振り、たまった水を抜きましよう。やわらかい布でから拭きするか、ハーモニカ除菌クリーナー（HAC-01）や消毒用エタノールを含ませた布できれいにしましょう。本紙に記載の無い薬品や溶剤などを使ってのお手入れは、製品を傷めますので絶対に使用しないでください。お手入れ後はケースにしまって保管してください。

## ⚠ リードに関する注意事項

### リードは折れることがあります

ハーモニカは内部で「リード」と呼ばれる小さな金属の板が振動し、音が鳴る仕組みです。リードは使用頻度や吹く息の強さによって金属疲労で音程が下がったり、亀裂が入ったり、また折れたりすることがあります。これはリードを使用した楽器全般に起こり得る現象です。

### 上を向いて演奏しないでください

ハーモニカは上を向いて演奏しないでください。万リードが折れた場合に、リード片が口に入ったり、吸い込んでしまう恐れがあります。もし吸い込んでしまった場合は、お近くの医療機関にご相談ください。

### リードが折れる前兆として

リードが折れる場合、前兆として音程が大きく下がります。その場合、ただちに演奏を中止してください。そのまま演奏を続けると、リード片が口に入ったり、吸い込んでしまう恐れがあります。

### リードは消耗品のため定期的なメンテナンスが必要です

弦楽器の弦が消耗によって切れることがあるように、リードも消耗によって音程が狂ったり、折れたりします。演奏の仕方や使用頻度によってリードの消耗状態は異なりますが、長く安全にお使いいただくため、定期的に弊社にメンテナンスをご依頼いただくことをお勧めいたします。

## 銀の変色について

ファビュラスの本体とカバーには銀鍍金が施されています。銀鍍金により滑らかな口あたりと抜けの良い音を実現しています。また銀には殺菌作用があり古くから食器や装飾品に貴重な金属として使用されています。銀は空気中のガスと反応し変色しやすい性質があります。使用後は必ず水分をふき取りやわらかい布等で全体を拭いてからしまってください。毎日お手入れすることで銀の独特の色調と音色、殺菌作用を持続させることができます。ひどく変色した場合は市販のシルバーポリッシュクロス（貴金属用磨き布）などで変色を取り除く事ができますが、クロスには研磨剤が含まれておりますので、頻繁に使用することは避けてください。

 **SUZUKI**

株式会社 鈴木楽器製作所

〒430-0852 浜松市中区領家2-25-12 TEL (053) 461-2325

<http://www.suzuki-music.co.jp/>

7106-5B-APR-MM-128-D

00457-10069v2.0

# FABULOUS

## SUZUKI 10HOLES FABULOUS F-20E/F-20J

**⚠ CAUTION** Please keep to the caution to protect from damage of your harmonica.

### **Before playing**

Wash your hands and rinse your mouth thoroughly. Also, play the each note slowly and carefully, and check if it is out of tune. When there is the tone which is tuned down drastically, the reed might be broken. Please stop playing in such case.

**Don't let any small object get accidentally inside your harmonica.**

This could cause damage to the harmonica.

**Don't grip the cover too tightly.**

You may bend the covers and damage the harmonica.

### **For protection**

In order to keep your harmonica protected, make a habit of storing it in its case when not in use.

**Don't throw or drop your harmonica.**

This could cause damage to the harmonica or hurt yourself.

**Keep your harmonica away from heat.**

Don't leave your harmonica near a source of heat such as an oven, or under intense sunlight. This could cause damage to the harmonica.

### **General care**

After playing, tap out the harmonica in the palm of your hand, and then wipe it with a soft, lint-free cloth. For more thorough cleaning, wipe with a cloth dampened with HAC-01 (Suzuki Harmonica Sterilization Cleaner) or ethanol for disinfection. Please never use any other chemicals or solvents not listed here to clean your harmonica, as they may damage it.

**⚠ Noted concerning the reeds**

### **The reeds can become break**

The harmonica is sounded by 'reeds', the small plates of metal inside. It vibrates to sound the notes. The reeds can become tuned down, crack or break due to the metal fatigue caused by the frequency of use or blowing strength of breath. This phenomenon is possible to happen to all of the reed instruments.

### **Do not play looking upward**

Do not play the harmonica looking upward. In case that the reeds become break, you can get the reeds into your mouth or inhale it. If you inhale the reeds, please consult to the nearest medical facility.

### **A sign of the reed breakage**

When your harmonica is tuned down drastically, it is a sign of reed breakage. Please stop playing in such case. If you keep playing, you can get the reeds into your mouth or inhale it.

### **The reeds are required regular maintenance since it is consumable goods**

As the strings of the string instruments are broken due to the consumption, the reeds can become out of tune or break as well. The lifetime of the reeds is depends on your playing style or how often you use your harmonica. Requesting regular maintenance to our company is recommended to use your harmonica safely for a long term.

### **Care of Silver plating**

The "FABULOUS" has a silver plated body and cover. This silver plating makes it smooth to handle and accentuates the very resonant sound. Precious metals like silver have been used for many years in creating the most high profile products, but is also known to tarnish easily in response to air. Please take special care of this harmonica and wipe off any moisture, over the whole harmonica, with a soft dry cloth after use. Daily care will keep your harmonica looking as good as new. In the case of bad tarnishing, you can use commercially available silver polishing cloths, but take care to avoid any cleaning agent on the parts where your mouth will come into direct contact. Please also avoid using any abrasive compound, which could damage the silver finish.



**SUZUKI MUSICAL INST. MFG. CO., LTD.**

2-25-12 Ryoke Naka-Ku Hamamatsu Japan

<http://www.suzuki-music.co.jp/>