

**▲ 注意** 安全に未永くご使用いただくため以下の指示を必ずお守りください。

●演奏の前に手を洗い、口をきれいにすすぎましょう。またゆっくり鳴らしてみても、音程がおかしくないか確認しましょう。通常より音程が大きく下がっている音があれば、リードが折れている可能性があります。その場合、使用しないでください。●吹口やすき間に異物を入れないでください。故障・破損の原因になります。●カパーを強く押ししたり、かんざししないでください。変形・破損の原因になります。また、変形してできたすき間に唇や舌などが入ると思わぬケガをする恐れがあります。●本製品を投げたり落としたりしないでください。破損するだけでなくケガがあり危険です。●車の中やストロブのすぐ近く、日ざしの強いところをおかないでください。変形・破損の原因になります。●演奏後は穴を下に向けて軽く振り、たまった水を抜きましょう。やわらかい布でから拭きするか、ハーモニカ除菌クリーナー (HAC-01) や消毒用エタノールを含ませた布できれいにしましょう。本紙に記載の無い薬品や溶剤などを使ってのお手入れは、製品を傷めますので絶対に使用しないでください。お手入れ後はケースにしまって保管してください。

**▲ リードに関する注意事項**

●本製品は内部で「リード」と呼ばれる小さな金属の板が振動し、音が鳴る仕組みです。リードは使用頻度や吹き息の強さによって金属疲労で音下がったり、亀裂が入ったり、また折れたりすることがあります。これはリードを使用した楽器全般に起こり得る現象です。●上を向いて演奏しないでください。万一リードが折れた場合に、リード片が口に入った、吸い込んでしまう恐れがあります。もし吸い込んでしまった場合は、お近くの医療機関にご相談ください。●リードが折れる場合、前兆として音程が大きく下がります。その場合、ただちに演奏を中止してください。そのまま演奏を続けると、リード片が口に入った、吸い込んでしまう恐れがあります。●弦楽器の弦が消耗によって切れることがあるように、リードも消耗によって音程が狂ったり、折れたりします。演奏の仕方や使用頻度によってリードの消耗状態は異なりますが、長く安全にお使いいただくため、定期的に弊社にメンテナンスをご依頼いただくことをお勧めいたします。

**<特長>**

スズキ和音笛Accord (アコード) には、メジャーとマイナーがあります。

メジャーセット (ACC-01) / ハ長調の主要3和音セット (C・F・G)

マイナーセット (ACC-02) / イ短調の主要3和音セット (Am・Dm・E)

本体が色で分かりやすく表示されており、より簡単に和音学習及びリズム学習が体験できます。



**<仕様>**

材質: ABS

寸法: 43×65×16mm (1個)

重量: 23g (1個)

付属品: プラスチックケース  
ホルダー

▼ ACC-01

メジャー『ハ長調』主要3和音	
青	C (ド・ミ・ソ)
黄	F (ド・ファ・ラ)
赤	G (シ・レ・ソ)

▼ ACC-02

マイナー『イ短調』主要3和音	
水色	Am (ド・ミ・ラ)
緑	Dm (レ・ファ・ラ)
ピンク	E (シ・ミ・ソ#)

株式会社 鈴木楽器製作所

〒430-0852 静岡県浜松市中区領家2-25-12 TEL (053) 461-2325 www.suzuki-music.co.jp

0208-5C-APR-MM-183-C

00454-10030 v3.0



# ACCORD MAJOR / MINOR OWNER'S MANUAL

# accord

ACC-01

ACC-02

**⚠ PRECAUTIONS** Follow the instructions below carefully for safe and long life use.

- Wash your hand and rinse your mouth before playing the ACCORD. And also, check whether the pitch is not wrong by gently blowing into the ACCORD. If the pitch is noticeably lower than normal, do not use as the reed might be broken or damaged (See CAUTION FOR REEDS). ● Do not put the extraneous material in the mouthpiece or the gap. It causes the failure or the damage. ● Do not push down strongly the cover or chew it. It causes the failure or the damage. Also, if your lips or tongue gets into the deformed gap, it may be in danger of the unexpected injury. ● Do not throw or drop the ACCORD. It is dangerous because it may cause injury as well as damage. ● Do not leave the ACCORD in or near a heat source such as direct sunlight, hot car or stove. It may cause deformation and breakage. ● After playing, remove accumulated moisture by shaking lightly with the mouthpiece facing downwards. Wipe the instrument with a soft cloth or clean with a cloth dampened with Suzuki Sterilizing Cleaner (HAC-01) or an Ethanol for disinfection. Do not use chemicals or solvents that are not described in this manual as they may damage the instrument. After cleaning, store the instrument in the protective case supplied.

**⚠ CAUTION FOR REEDS**

- The sound of the ACCORD is produced by a small reed located on a metal plate vibrating at a specific frequency. Depending on the frequency of use and the strength of the breath you breathe, the reed may drop the pitch, crack, or break due to metal fatigue. This is a phenomenon that can occur with all reed instruments. ● Do not play the instrument face up. If the reed is damaged, you may accidentally swallow or inhale a fragment of the broken reed. If this occurs, seek medical advice immediately. ● If the reed breaks, the pitch will drop significantly as a precursor. In that case, stop playing immediately. If you continue playing, the reed may get into your mouth or inhale. ● Just like the stringed instrument breaks the string due to exhaustion, the reed also goes out of pitch or breaks due to exhaustion. Depending on how you play and how often you use the reed, the state of wear of the reed will vary, but we recommend that you regularly ask for maintenance to ensure long and safe use.

## < PRODUCTS >

Suzuki chord whistle "Accord" has major and minor.

**MAJOR set (ACC-01) / Major 3 chords set in C major (C•F•G)**

**MINOR set (ACC-02) / Major 3 chords set in A minor (Am•Dm•E)**

Each instrument is distinguished by a different color to aid easily in learning chord and rhythm.



## < SPECIFICATIONS >

Material : ABS  
 Size : 43 x 65 x 16mm (per a unit)  
 Weight : 23g (per a unit)  
 Accessory : Plastic case / holder

ACC-01 / C major 3chords		ACC-02 / A minor 3chords	
Blue	C (C•E•G)	Light blue	Am (C•E•A)
Yellow	F (C•F•A)	Green	Dm (D•F•A)
Red	G (B•D•G)	Pink	E (B•E•G#)

**SUZUKI MUSICAL INST. MFG. CO., LTD.**

2-25-11, Ryoke, Naka-ku, Hamamatsu, 430-0852 Japan Tel: 81-53-460-3781 [suzukimusic-global.com](http://suzukimusic-global.com)